

# **DEAP Heat Pump Methodology 2020**

For Heat Pump configurations not covered in DEAP 4 software

# **DEAP Heat Pump Methodology 2020**

For Heat Pump configurations not covered in DEAP 4 software

Latest update: August 2024

#### **Disclaimer**

While every effort has been made to ensure the accuracy of the contents of this report, SEAI accepts no liability whatsoever to any third party for any loss or damage arising from any interpretation or use of the information contained in this report, or reliance on any views expressed therein. Public disclosure authorised. This guide may be reproduced in full or, if content is extracted, then it should be fully credited to SEAI.

#### **Sustainable Energy Authority of Ireland**

SEAI is Ireland's national energy authority investing in, and delivering, appropriate, effective, and sustainable solutions to help Ireland's transition to a clean energy future. We work with the public, businesses, communities, and the Government to achieve this, through expertise, funding, educational programmes, policy advice, research, and the development of new technologies.

SEAI is funded by the Government of Ireland through the Department of Communications, Climate Action, and Environment.

© Sustainable Energy Authority of Ireland Reproduction of the contents is permissible provided the source is acknowledged.

# **Contents:**

1	INT	RODUCTION	2
	1.1	USING THE HEAT PUMP CALCULATOR WITH DEAP	3
	1.2	OVERVIEW OF THE HEAT PUMP CALCULATOR TABS	4
2	TES	T DATA AND HEAT PUMP TYPES	5
	2.1	GROUP HEATING AND MULTIPLE HEAT PUMP SCENARIOS	6
3	EX.	AMPLES	9
	3.1	DEAP ENTRIES TAB: GUIDANCE ON VALUES SOURCED FROM THE DEAP ASSESSMENT	10
	3.2	DEAP ENTRIES TAB: VALUES RETURNED FROM THE HEAT PUMP CALCULATOR FOR DEAP	15
	3.3	LOW TEMPERATURE HEAT PUMPS	18
	<i>3.3</i> .	1 Low temperature heat pump for space heating only. Individual heating system	18
	3.3.	2 Low temperature heat pump for space heating only with a separate water heating heat pump	22
	3.4	DX HEAT PUMP	25
	3.5	GAHPs	
	3.6	Exhaust Air-to-Air systems	
	3.7	Multiple Heat Pumps in Dwelling	32
	3.8	GROUP HEATING SYSTEM EXAMPLES	35
	<i>3.8</i> .	1 Group heating heat pump with group heating CHP / solar space heating / boilers	35
	3.8	2 Multiple heat numps in the group heating system	40

Change Log:

Section	Change from version 2.0
1	Minor text changes to explain that the tool cannot be used for cascade configurations.
1.1	Removed the reference to the RER adjustment for group heating. This is no longer in the DEAP 2020 HP methodology as it is calculated in the DEAP software.
2.1	Text changes to explain that the tool cannot be used for cascade configurations Inclusion of table with simplified schematics of heat pumps in series, parallel and cascade  Added text for cases with identical heat pumps in parallel
3.1	Text changes in the description of input "Is heat pump source preconditioned?" as this should not apply to cascade systems.
3.1	Updated references to the DEAP software sections as "View Assessment" has been removed.
3.8.1	Removed the paragraph and screenshot related to the RER adjustment for group heating as it no longer applies.
3.8.2	Replaced screenshot as the "heat pump source pre-conditioned" does not apply.

#### Introduction

This document supplements the DEAP Manual, the DEAP software (<a href="https://deap.seai.ie/">https://deap.seai.ie/</a>) and accompanies the Microsoft Excel DEAP Heat Pump Calculator 2020, published by SEAI. The calculator and this guidance facilitate entry of heat pump types and systems not catered for in the DEAP software, and follows changes proposed in the document "DEAP Heat Pump Methodology Proposed Changes" issued for public consultation by SEAI in Q2 2019. This calculator and guidance must be used when calculating efficiencies for use in residential BER assessments and/or Part L compliance calculations for the following systems incorporating heat pumps in any of the following scenarios:

- **Low Temperature Heat Pump:** These are Low Temperature "to-water" units as defined in the Ecodesign directive which cannot deliver heating water at a temperature at or above 52°C1.
- Gas adsorption/absorption Heat Pumps (called GAHP in this document): These heat pumps consume gas rather than electricity. The test data for these units is structured in the same way as electrical heat pumps but is based on different test standards detailed in Section 2 of this document.
- **Direct Exchange (DX) heat pumps:** These units circulate refrigerant rather than water through the ground loop. For the purposes of this calculator, they are similar to Brine /Water (B/W) units, although the source temperature is 4°C rather than 0°C.
- Exhaust Air to Air heat pumps: These are double duct systems using heat pump technology to source heat from extracted air to heat incoming fresh air. Like Exhaust Air to Water heat pumps already facilitated in the DEAP software, the renewable energy contribution is adjusted as energy recovered from the dwelling via heat recovery is not considered renewable in line with the Renewables Directive (2018/2001).
- **Multiple Heat Pump Arrangements:** The heat pump calculator facilitates multiple heat pumps in certain configurations. It includes up to three heat pumps, with means to separate space and water heating heat pumps, in series or parallel<sup>2</sup>. The combined efficiency of the three heat pumps may be entered as group heating or individual heat pumps, or combinations thereof. The user enters proportion of space heating and water heating from each heat pump as well as heat pump type information and associated test data for each unit. This document details relevant test data / standards for these heat pump types in Section 2 and demonstrates how to account for each type in Section 3.

This calculator enables DEAP users to account for the above system types using the current version of the DEAP 4 software.

The "DEAP Heat Pump - Designer/ Installer Sign Off Form" facilitates the heat pump types and associated standards included in the DEAP Heat Pump Calculator 2020, referred to as heat pump calculator in this guidance document. When carrying out heat pump analysis for DEAP using the heat pump calculator, the BER Assessor must upload the heat pump calculator and Designer/installer sign off excel files used for the BER assessment as evidence when completing the DEAP software online assessment.

August 2024

<sup>&</sup>lt;sup>1</sup> As per Ecodesign Regulation 813/2013: 'low-temperature heat pump' means a heat pump space heater that is specifically designed for low-temperature application, and that cannot deliver heating water with an outlet temperature of 52 °C at an inlet dry (wet) bulb temperature of -7 °C (-8 °C) in the reference design conditions for average climate;

<sup>&</sup>lt;sup>2</sup> The DEAP Heat Pump Calculator 2020 excludes heat pump configurations in cascade.

# 1.1 Using the Heat Pump Calculator with DEAP

As this calculator and guidance supplement the DEAP software, please ensure to follow the DEAP Manual, particularly "Appendix G: Heat Pumps". The text from the DEAP Manual is generally not replicated in this guidance document but is referenced where necessary. However, there are aspects of the interaction with the DEAP Manual and Software to bear in mind when using this calculator:

- A number of DEAP software entries must be completed for the dwelling in question prior to using this calculator. Namely:
  - Building and Ventilation sections. This enables DEAP to calculate fabric heat losses and therefore the space heat demand for the heat pump.
  - Space heating -> Controls and Responsiveness; as well as Pumps and Fans
  - Water heating -> Options and Storage; as well as Solar thermal (if applicable). This enables
     DEAP to calculate the water heat demand for the heat pump.
  - Lighting
- The "DEAP Heat Pump Designer/ Installer Sign Off Form" must be completed by the heat pump system Designer/ Installer in advance of using the Heat Pump Calculator.
- A number of data points, such as dwelling heat demand, are then sourced from the DEAP software and
  manually entered into the Heat Pump Calculator. This guidance document details how to source these
  figures from DEAP and use them in the heat pump calculator.
- A number of data points, such as heat pump test data, are entered and used in this calculator for the
  aforementioned heat pump types (e.g. GAHP). Sourcing and using these test figures is similar to the
  process for heat pumps already catered for in DEAP (e.g. electrical A/W heat pumps with Ecodesign
  based data).
- The heat pump calculator shades out fields not relevant to the entries made by the user.
- Results from this calculator (such as heat pump system efficiencies) are manually entered in the DEAP software assessment as described in this document. DEAP uses these calculator results to determine overall energy usage for space and water heating and Renewable Energy Part L compliance contribution checks.
- When using the heat pump calculator, add a note to the "Assessor Comments" section in DEAP under "Edit Survey Details" referencing use of the heat pump calculator, and, where relevant, the Renewable Energy Ratio adjustment described in this document.
- Note that like electric heat pumps, the renewable contribution from GAHP is based on the heat provided by the heat pump minus the fuel (gas in this case) supplied to the heat pump. This is the ambient (renewable) energy the heat pump sources from the environment.
- When heat pump efficiencies are manually entered in the DEAP software, DEAP calculates the associated renewable energy contribution for the purposes of Part L compliance checking (Renewable Energy Ratio, or, RER). This may need to be adjusted in certain scenarios. The extent of the adjustment is automatically calculated by the heat pump calculator and is used to adjust the overall RER as detailed in this document. Scenarios involving this adjustment are:
  - Calculated heat pump efficiency includes a combination of heat pump and backup heating
  - Reduction in renewables due to use of Exhaust Air as a heat source
  - Reduction in renewables for any heat pump with its heat source preheated by another heating system. For example, a heat pump with a boiler providing heat to its "source loop" or a heat pump with its source preheated by another heat pump).
  - The adjustment is not required in cases where the Part L renewable energy ratio is not relevant in DEAP (i.e. existing dwelling BER assessments). It is only required for new-final and newprovisional assessments.

 Where Part L RER is relevant (i.e. New final or new provisional assessment), a copy of the "DEAP Entries" sheet from the completed heat pump calculator must be provided with the Part L compliance report and client must be advised in writing of the change to RER.

# 1.2 Overview of the Heat Pump Calculator tabs

There are a number of tabs in the Heat Pump Calculator. These are similar to the original Heat Pump Calculator published in 2016 (and subsequently integrated with the DEAP software):

- **Cov; Code; Proj tabs**: These are the cover sheet, the overview of the different tabs and the basic information about the dwelling and assessment respectively.
- **DEAP Entries tab**: This tab takes fields manually transferred from DEAP by the Assessor for use in the Heat Pump Calculator. It also presents the final results from the calculator to be transferred by the Assessor into DEAP. This user carries out RER adjustment where required on this tab.
- There are three of each of the following tabs. This allows for up to three systems to be entered and analysed in the calculator:
  - o HP\_1, HP\_2, HP\_3 tabs: User enters design and test data for up to three heat pumps.
  - HeatingCalc\_1 / 2 / 3: Carries out space heating calculations based on the dwelling heat demand and the above inputs for up to three heat pumps. There are no user entries on these tabs.
  - DHWCalc\_1 / 2 / 3: Carries out water heating calculations based on the dwelling hot water demand and the above inputs for up to three heat pumps. There are no user entries on these tabs.
  - SpaceStandardsID\_1 / 2 / 3 and WaterStandardsID\_1 / 2 / 3: used by each HP tab to check
    if the user has selected valid entries heat pump types and associated standards. There are no
    user entries on these tabs.
- Meteorological data: Holds weather data from ASHRAE for use in the Heat Pump Calculator.

# 2 Test data and heat pump types

Table 1 below shows the applicable test data for all heat pump types catered for in the DEAP methodology as well as detailing the scenarios for which this Heat Pump Calculator is used, and those for which the DEAP software is used. Additional information is provided on group heating functionality and requirements in Section 2.1 below. Table 1 shows the following information:

- Heat pump type (e.g. Air to Water, Direct Exchange etc.)
- Specify the fuel: electricity or gas (GAHP)
- Differentiate between space and water heating for each heat pump type
- Specifies the relevant standard for each heat pump type and each heat use. For example:
  - space heating standard for a GAHP is EN12309-6<sup>3</sup>.
  - water heating standard for an electric heat pump is EN16147<sup>4</sup>.
  - water heating standard for a GAHP is EN13203-6<sup>5</sup>.
- Specifies the relevant source temperatures for tests. For example:
  - $\circ$  test points use source temperature of 4°C for DX units and 0°C for brine source units.
- Specify relevant sink temperatures for each of fixed control and variable control units. For example:
  - o in a medium temperature application, the sink temperature at all 5 test points is 45°C for a fixed control "to-water" unit
  - in a medium temperature application, the sink temperature at the test points varies:  $43^{\circ}$ C;  $37^{\circ}$ C;  $33^{\circ}$ C;  $28^{\circ}$ C;  $45^{\circ}$ C for a variable control "to-water" unit
- Outlines the heat pump types that are specifically classed as "Low Temperature". The Heat Pump Calculator must be used in this case. Notes:
  - While Low Temperature units do not provide hot water, a separate hot-water only heat pump may be specified for the same dwelling, or the Low Temperature Heat Pump may "pre heat" the hot water in the Heat Pump Calculator (this is the sole exception to the rule where "Low temperature heat pumps" do not ordinarily provide hot water).
  - Ordinarily "High temperature" test data, as shown in the table, must always be provided for "to-water" units for space heating. However, in the case of low temperature units, "Low temperature" test data is mandatory and "medium temperature" test data is optional for use in the Heat Pump Calculator.
- The following must currently be assessed in the Heat Pump Calculator:
  - all "Low temperature" units;
  - GAHPs;
  - DX units;
  - Exhaust Air to Air,
  - Heat pumps in group heating systems
  - Systems with multiple heat pumps.
  - Other systems are generally assessed using DEAP as shown in the table.
- Other Notes for Table 1:
  - source/ sink temperatures and test points shown are based on the relevant standards and Ecodesign Directive requirements.
  - GAHPs use the same source and sink temperatures as corresponding electric A/W, B/W and W/W units.

<sup>&</sup>lt;sup>3</sup> I.S. EN 12309-6:2014: Gas-fired sorption appliances for heating and/or cooling with a net heat input not exceeding 70 kW - part 6: calculation of seasonal performances

<sup>&</sup>lt;sup>4</sup> References for electrically driven heat pumps are provided in the DEAP manual.

<sup>&</sup>lt;sup>5</sup> EN 13203-6:2018: Gas-fired domestic appliances producing hot water. Assessment of energy consumption of adsorption and absorption heat pumps

# 2.1 Group heating and multiple heat pump scenarios

The calculation of efficiency for heat pumps in group heating systems, whether served by single or multiple heat pumps, requires use of the heat pump calculator. Individual systems served by multiple heat pumps also requires the use of the heat pump calculator. The examples later in this document illustrate the approach. A number of scenarios for space/water group heating are catered for in the Heat Pump Calculator such as:

- Single heat pump heating several dwellings;
- Single heat pump heating several dwellings with secondary heating in the dwelling (e.g. stove);
- Single heat pump with boiler and/or solar space heating supplying heat to several dwellings with/without secondary heating in the dwelling;
- Any of the above with Combined Heat and Power (CHP) meeting some of the heat demand;
- Group heat pumps providing "pre-heat" in series with group or individual heat pumps;
- Group heat pumps in parallel configurations
- Group heat pump heating multiple dwellings also containing individual boilers within dwellings;
- Two or more heat pumps in the heating system within a dwelling.

The DEAP Heat Pump Calculator 2020 cannot be used for group or multiple heat pumps in cascade configuration. BER Assessors should consult with the Helpdesk in case of cascade or other group systems involving heat pumps with a number of different sources with complex schematics.

The following table illustrates examples of different heat pump configurations.

Configuration	Examples of simplified Schematics <sup>6</sup>	Note
In parallel	HP1 ASHP Air source HP2 ASHP	Heat pumps in parallel have common outlet and inlet temperatures.
In series	Air source  Air source  HP1  ASHP  ASHP  ASHP	The inlet temperature of HP2 is the same as the outlet temperature of HP1.
In cascade	Air source  HP1 ASHP  Water source  HP2 WSHP	The flow and return to the system are connected to HP2. HP1 does not provide heat directly to the system, it is used to provide a heat source for HP2.

<sup>&</sup>lt;sup>6</sup> Only simple examples are included here. Actual schematics are much more complex and may include different heat pump types and sources.

August 2024

When there are two or more identical heat pumps, both heating the same circuit in parallel, they may be entered as one heat pump with equivalent heat output. To account for the equivalent heat output, the capacities (Pdh) at each test point needs to be multiplied by the number of heat pumps. The declared COP for each test point applies as it is (this must not be multiplied).

If the heat pumps are different, if they are heating different floor areas, or are not configured in parallel, then they may not be entered as a single heat pump.

				Sink temps (fixed) deg C			Sink temps (variable) deg C								
	I			_	@ part loads					ds: 88%; 54%					
Heat pump type	Electric/ GAHP?	Space heating? Water heating?	Test standard	Source temps degC	Low temp application	Medium temp	temp		Low temp application	Medium temp	High temp	Very high temp	How to treat low temperature version of this heat pump	Approach where ecodesign n/a	DEAP Software or Heat Pump Calculation tool applies?
A/W	Electric	Space	EN14825:2016 Table 8, 9, 10, 11	-7; 2; 7; 12; TOL	35	45	55	65	34; 30; 27; 24; 35	43; 37; 33; 28; 45	52; 42; 36; 30; 55	61; 49; 41; 32; 65	"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.	DEAP Appendix G/HARP and Table 4c. EN14511/255-2/255-3	Only use this calculation tool for: . Low Temperature units or . if EN14825/14511 used for DHW or
		Water	EN16147	7		Refere	ence ho	t water	r temperature	in EN16147 t	est		No DHW mode for low temp option	EN14311/233-2/233-3	. Multiple HPs / group system
B/W	Electric	Space	EN14825:2016 Table 12, 13, 14, 15 EN16147	0		All sink test points identical to A/W electric heat pumps		"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.  No DHW mode for low temp option	DEAP Appendix G/HARP and Table 4c. EN14511/255-2/255-3	Only use this calculation tool for: . Low Temperature units or . if EN14825/14511 used for DHW or . Multiple HPs / group system Otherwise use DEAP software					
W/W	Electric	Space	EN14825:2016 Table 12, 13, 14, 15	10		All sink test points identical to A/W electric heat pumps			"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.	DEAP Appendix G/HARP and Table 4c. EN14511/255-2/255-3	Only use this calculation tool for: . Low Temperature units or . if EN14825/14511 used for DHW or . Multiple HPs / group system Otherwise use DEAP software				
		Water	EN16147	10							52: 42:	61: 40:	No DHW mode for low temp option  "Low temp application" mandatory. "Medium		Only use this calculation tool for:
ЕАНР	Electric	Space Water	EN14825:2016 Table 8, 9, 10, 11 EN16147	20	35	45 55 65 34; 30; 27; 43; 37; 33; 36; 30; 41; 32; 24; 35 28; 45 55 65		temp application infinitional. High temp mandatory if not low temp heat pump.  No DHW mode for low temp option	DEAP Appendix G/HARP and Table 4c. EN14511/255-2/255-3	. Low Temperature units or . Low Temperature units or . if EN14825/14511 used for DHW or . Multiple HPs / group system					
		water	EN14825 Table 12,	20		Reference hot water temperature in EN16147 test		"Low temp application" mandatory. "Medium	DEAP Appendix G/HARP	. Multiple HPS / group system					
Direct exchange (DX)	Electric	Space	13, 14, 15 (4 degrees source)	4		All sink te	est poin	nts iden	tical to A/W e	electric heat p	umps		temp application optional". High temp mandatory if not low temp heat pump.	and Table 4c. EN14511/255-2/255-3/	Use Heat Pump Calculation tool for all DX units
		Water	EN16147	4									No DHW mode for low temp option	EN15879-1	
A/A	Electric	Space	EN14825:2016 Table 6	-7; 2; 7; 12; TOL		20			No additional "low temp" option.	DEAP Appendix G/HARP and Table 4c. EN14511/255-2	Only use this calculation tool for: . Multiple HPs / group system Otherwise use DEAP software				
в/А	Electric	Space	EN14825:2016 Table 7	0					20				No additional "low temp" option.	DEAP Appendix G/HARP and Table 4c. EN14511/255-2	Only use this calculation tool for: . Multiple HPs / group system Otherwise use DEAP software
W/A	Electric	Space	EN14825:2016 Table 7	10					20				No additional "low temp" option.	DEAP Appendix G/HARP and Table 4c. EN14511/255-2	Only use this calculation tool for: . Multiple HPs / group system Otherwise use DEAP software
Double duct air conditioner / Exhaust Air to Air	Electric	Space	EN13141 (See EN14511:2018 table 3 as per DEAP Manual)	-15; -7; 2; 7; 12 (20 for EA/A)		20		No additional "low temp" option.	Ecodesign doesn't apply for space heating for these units.	Only use this calculation tool for: Exhaust Air to Air or If EN14825/14511 used for DHW or Multiple HP5/group system Otherwise use DEAP Software for these units.					
		Water	EN16147	7		Refere	nce ho	t water	temperature	in EN16147					Additional guidance DEAPG4.3
A/W	GAHP	Space	EN12309-6:2014 Table 5, 8, 11, 14	-7; 2; 7; 12; TOL	35	35		"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.	n/a	Use Heat Pump Calculation tool for all GAHP units					
		Water	EN 13203-6	7		Reference hot water temperature in 13203-6 test		No DHW mode for low temp option							
B/W	GAHP	Space	EN12309-6:2014 Table 17, 20, 23, 26	0		All sink test points identical to A/W GAHP		"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.	n/a	Use Heat Pump Calculation tool for all GAHP units					
		Water	EN 13203-6	0				No DHW mode for low temp option							
w/w	GAHP	Space Water	EN12309-6:2014 Table 17, 20, 23, 26 EN 13203-6	10		All sink test points identical to A/W GAHP		"Low temp application" mandatory. "Medium temp application optional". High temp mandatory if not low temp heat pump.	n/a	Use Heat Pump Calculation tool for all GAHP units					
		water	EN 13203-6	10									No DHW mode for low temp option		

Table 1: Overview of standards, test points and heat pump types

# 3 Examples


This section sets out a number of examples of the systems to be assessed using the Heat Pump Calculator and does not focus on heat pump types already catered for in the DEAP software. Generally, the standards/Ecodesign based data is of the same format/requirements as heat pumps facilitated in the original 2016 DEAP Heat Pump Methodology and now, in the DEAP software. The same Ecodesign directive and regulations apply to low temperature, DX and GAHP heat pumps, so Ecodesign test data already in use by BER Assessors since 2016 is not replicated in this document.

#### 3.1 DEAP Entries tab: guidance on values sourced from the DEAP assessment


Section 1.1 details that the building, ventilation, and lighting sections as well as parts of the space and water heating sections of the DEAP assessment must be completed to generate relevant inputs for the Heat Pump Calculator. The "DEAP Heat Pump - Designer/ Installer Sign Off Form" must also be completed in advance of using the Heat Pump Calculator. These are entered in the "DEAP Entries" tab (yellow cells) and are sourced as explained in this table and applies to the examples detailed later in this document.

**Table 2: Sourcing data from DEAP** 

Description:	Unit:	Guidance Notes:							
Total heat loss (W/K) taken	W/K	Sourced from DEAP "results" tab as per the screenshot. This is the sum of heat losses from fabric + ventilation + windows:							
from DEAP		Space Heating  Water Heating  Doors  Doors  Doors  Doors  Total Heat Loss  Total Heat Loss							
Annual space heat requirement (total)	kWh	Sourced from DEAP: results -> gains/losses -> heat emitter  DEAP4 > Survey  BER: 11745							
		Renewables  LIGHTING GAINS/LOSSES  Results							
		C=) Evidence SPONSIVENESS SOUR							
		HEAT EMITTER							
		Fraction of heating system output from ground floor  Additional heat loss via envelope element [kWh/y]  Annual space heating requirement [kWh/y]  563.89							
Floor Area of Dwelling	m <sup>2</sup>	Sourced from DEAP: Building: Floors tab.							
Living area of dwelling	m <sup>2</sup>								



Electricity		Sourced from DEAP: Results -> results View						
Primary Energy Factor								
		© Building DEAP4 > Survey						
		Ventilation RESULTS PAI >						
		Space Heating						
		Water Heating FUEL FACTORS						
		Space Cooling emissions Energy Emissions						
		Q Lighting [kg/y] Current 1.75 0.224 Ene						
		Renewables 0 SIMULATE						
		Results ASSESSMENT 250 USING PREVIOUS						
		GD Evidence						
Volume of DHW Storage	litres	Sourced from DEAP: Water Heating: options and storage						
		Storage  Is hot water storage indoors or in group heating scheme?  Storage Type  Storage Volume [I]  250						
Type of space heating heat pump Type of water heating heat pump		The user can specify the heat pump type for space and water heating separately for up to three heat pumps. These will be one of "None"; "Heat Pump"; "Exhaust Air Heat Pump", based on the "DEAP Heat Pump - Designer/ Installer Sign Off Form" & Ecodesign Data sheet for the Heat Pump.						
% main space /	%	Sourced from design data for space and water heating for up to three heat pumps.						
water heat provided by each heat pump based on system		In individual heating systems, these values must always total 100% for each of space heating and water heating where there is one or more space heating or water heating heat pump installed.						
design		In group heating systems, the sum of these values for each of space heating and water heating will depend on the presence of other heating systems in the design (e.g. group heating boilers or solar space heating).						
		The proportions of heat from conventional boilers (and other systems such as heat pumps) should be estimated based on operational records or, in the case of a new scheme, on the basis of its design specification. The heat pump will provide 100% minus [the percentage from solar space heating + percentage from boilers] towards the space and water heat demand. In the example shown, the boiler + solar space heating provides 47%. Therefore, the proportion of group heating provided by heat pump will be 53%. The designer/installer should provide the resulting estimate of space heating and water heating from the installed heat pump(s) for use in the heat pump calculator.						
		Where no design specification or operational records are available, the assessor should proportion the heat pump contributions based on the capacity of each heating system.						



<sup>&</sup>lt;sup>7</sup> The DEAP Heat Pump Calculator 2020 cannot be used for group or multiple heat pumps in cascade configuration.

Total renewables kWh primary energy	Sourced from [	DEAP: Results: Pa	art L			,
from DEAP software		CONFORMITY W	ITH RENEWABLE E	ENERGY TECHNOLOG	GIES REQUIREMEN	Т
Total primary energy from			Source	Renewables Primary Energy	Total Primary Energy	
DEAP software		+ Delivered energy	PV/Wind	0.000	0.000	
		+ Delivered energy	Other	0.000	0.000	
		+ Delivered energy	Solar	0.000	0.000	
		+ Delivered energy	Biomass	0.000	0.000	
		+ Delivered energy	Biodiesel	0.000	0.000	
		+ Delivered energy	Bioethanol	0.000	0.000	
		+ Environmental energy	HP	302.661	302.661	
		+ Saved energy	CHP	63.927	0.000	
		+ District heating	District Heating	0.000	0.000	
		+ Delivered energy	Grid	0.000	2,639.408	
		+ Delivered energy	Thermal	0.000	1,464.368	
		SUBTOTAL		366.588	4,406.437	
		Energy not used in Regulated Loads	PV/Wind/CHP	0.000	0.000	
		TOTAL		366.588	4,406.437	

# 3.2 DEAP Entries tab: values returned from the Heat Pump Calculator for DEAP

Once the Heat Pump Calculator entries are completed as detailed in the examples later in this document, the calculator returns a number of fields (in blue cells in the DEAP Entries tab) for entry in DEAP. Entering these fields in the DEAP software is carried as outlined in the following tables for the examples detailed later in this document. Table 3 details the approach to each result from the DEAP Entries tab.

**Table 3: Returning data to DEAP.** 

Description:	Unit:	Guidance Notes:
Efficiency of space	%	Enter in DEAP: Space heating: heat source as heating system efficiency. For group heating
heating heat pump +	/0	system, always enter as the first heat pump system in DEAP.
backup		system, always enter as the first heat pump system in DEAP.
Efficiency of water	%	Enter in DEAP: Water heating: heat source as heating system efficiency. For group heating
heating heat pump +		system, always enter as the second heat pump system in DEAP.
backup		
Space heating fuel and		Space heating fuel: Enter in DEAP: Space heating: heat source as fuel. Gas fired heat pumps
water heating fuel		treated as natural gas / LPG boilers (with efficiency as derived by this calculation). For group
		heating system, enter as the first heat pump system in DEAP.
		   Water heating fuel: Enter in DEAP: Water heating: heat source as fuel. Gas fired heat pumps
		treated as natural gas / LPG boilers (with efficiency as derived by this calculation). For group
		heating system, always enter as the second heat pump system in DEAP.
Efficiency adjustment		These will always be "1" when using the heat pump calculator.
factor for space heating		mose i.m. aays see it which asing the heat pump culculator.
and water heating		
Group heating % of heat	%	This value only applies to systems with a group heating heat pump. It must be entered as
from space heating		the <u>first</u> heat pump system percentage of heat in the DEAP Software so that the renewable
		contribution and adjustment thereof is calculated correctly.
Group heating % of heat	%	This value only applies to systems with a group heating heat pump. It must be entered as
from water heating		the <b>second</b> heat pump system percentage of heat in the DEAP Software so that the
		renewable contribution and adjustment thereof is calculated correctly.
Additional errors and		If this error is shown, the heat pump test temperatures are lower than expected by the
warnings #1		proportion of water heating set by the user. Either the proportion of heat from this heat
		pump will need to be lowered or alternative (valid) test data is required.
Additional errors and		This warning indicates that backup heating is deemed necessary by the heat pump
warnings #2		calculator. Alternative heat pumps (e.g. larger capacity) or reproportioning of heat may
A 1 1242		alleviate the issue and improve overall system efficiencies).
Additional errors and		While the heat pump calculator allows the standard IS EN 14825/14511 to be used in place
warnings #3		of IS EN 16147 for water heating, it may not be used for more than one of the three heat
DEAD Entries: Peneur	oblo Enor	pump iterations facilitated in the heat pump calculator.  rgy Adjustments (fields completed AFTER results from table above complete). New
DLAF LITTIES. Reliew	able Lilei	dwellings only.
Total renewables primary	kWh	Sourced from DEAP: Results: Part L after completion of the BER assessment
energy from DEAP		Refer to Table 2.
software		
Total Primary Energy from	kWh	
DEAP software		
Adjusted Renewable	kWh	Calculated by the Heat Pump Calculator. The Assessor is required to:
Energy Ratio to be		- Add note to the "Assessor Comments" section in DEAP
attached to compliance		<ul> <li>notify the client in writing of this result,</li> </ul>
report.		- attach the Heat Pump Calculator to evidence in the DEAP software
		AND
		- attach the result to the Part L compliance report.

Table 4 outlines how each system type is treated when porting results from the calculator to DEAP

Table 4: Summary of heat pump types: approach in DEAP


Group/ individual system:	Heat pump type:	Fuel type in DEAP	Heating system selected in DEAP	Efficiencies	Renewables	Controls comment
Individual	Any electric individual heat pump including:  . Exhaust air to air . DX . Electric Low temp heat pumps	Electricity	Direct acting electric boiler	As calculated by heat pump calculator. NB space and water heating efficiencies will differ so need to be entered separately. Deselect the option "heats water" when entering the space heating details of the heat	Relevant for new dwellings for all heat pump system types.  When heat pump efficiencies are manually entered in the DEAP software,	Enter in DEAP as per the system installed in the dwelling. Efficiency adjustment factor must = 1.0 when sourcing results from the heat pump calculator.
Individual	Any GAHP individual heat pump including:  . A/W . B/W . W/W . Gas low temp. heat pumps	Mains gas or LPG as supplied to the dwelling	Regular non- condensing gas boiler	pump in DEAP.	DEAP calculates the associated renewable energy contribution for the purposes of Part L compliance checking (Renewable Energy Ratio, or, RER). This	Enter in DEAP as per the system installed in the dwelling. Non-condensing option with interlock gives Efficiency Adjustment Factor of 1.0 in DEAP. Efficiency adjustment factor must = 1.0 when sourcing results from the heat pump calculator.
Individual heating system with multiple heat pumps	Combination of heat pump types above	As per electric or GAHP guidance in this table above depending on whether all heat pumps are electric or GAHP.	As per electric or GAHP guidance in this table above depending on whether all heat pumps are electric or GAHP.		may need to be adjusted in certain scenarios. The extent of the adjustment is automatically calculated by the	As per electric or GAHP guidance in this table above depending on whether all heat pumps are electric or GAHP.
Group heating: single heat pump and systems with multiple heat pumps	Single heat pump type or combination of heat pump types as above	Electricity, mains gas or LPG as above	Group heating scheme	Enter space heating efficiency, proportion, and fuel as heating system #1 in group heating section of DEAP Software. Enter water heating efficiency, proportion, and fuel as heating system#2 in group	heat pump calculator and is used by the Assessor to adjust the overall RER as detailed in this document.	Enter in DEAP as per the system installed in the dwelling.

		heating section of DEAP	
		software.	
		Total percentage of heat	
		including additional boiler	
		and solar space heating	
		must = 100% in DEAP	
		software.	


# 3.3 Low temperature heat pumps

#### 3.3.1 Low temperature heat pump for space heating only. Individual heating system.


This example is based on a single heat pump defined as a Low Temperature heat pump under the Ecodesign directive. The heat pump complies with Ecodesign/Energy Labelling directive. As it is a low temperature unit, it does not provide water heating. In this example, water heating is provided by a gas boiler, meaning that "Type of water heating heat pump" is set to "none". As there is only one heat pump, space heating entries for heat pumps #2 and 3 are not populated. Data is entered in yellow cells in the heat pump calculator. The DEAP Entries tab is populated as per guidance in Table 2 above based on information in the DEAP Software as follows:




Along with the DEAP Entries being completed, the user completes a number of entries in the **HP\_1 tab** of the Heat Pump Calculator based on the "DEAP Heat Pump - Designer/ Installer Sign Off Form", starting with some basic information about the heat pump. The Heat Pump Calculator flags cases where valid or invalid entries are made (e.g. the wrong standard is chosen based on heat pump type and applicability of Ecodesign). The "WTOL" entry highlighted below is sourced from test data and must be < 52°C for low temperature heat pumps:




Entries related to heat emitters, backup heating, heat pump operation limit temperatures etc. all use the same approach as heat pumps assessed directly within the DEAP software following DEAP Appendix G. Note that for a Low Temperature heat pump, the unit is designed for lower emission temperatures (e.g. underfloor heating or system with radiators designed to run at a lower temperature). The entries for the example in question are as follows:




The user specifies the test data available for this unit. "High temperature" and "Very high temperature" data are not appropriate or available for "Low temperature" heat pumps. While "medium temperature" data is optional for this type of heat pump, it is not assumed to be available for this example. "Low temperature" is mandatory for "low temperature" heat pumps, so is set to "yes". The corresponding COPs and capacities are entered at each of the five test points such as in the following example:



In this example, as "Type of water heating heat pump" is set to "none", then no water heating entries are required. The results for space heating are now automatically updated in the DEAP Entries tab as follows.




No adjustment is required for renewables in this case (as shown by the "0" value) automatically calculated by the heat pump calculator in the following figure. Note also that the calculator advises the user that a backup is indicated as being necessary. Alternative heat pumps (e.g. larger capacity) or reproportioning of heat may alleviate the issue and improve overall system efficiencies).



The efficiency and heating system are populated by the Assessor in DEAP as per Table 3 and Table 4 above.

Fuel type in DEAP is electricity. Heating system entered in DEAP is "Direct acting electric boiler" with efficiency as per the following diagram. Selecting this option enables DEAP to show control options suitable for a heat pump. In addition, this option enables DEAP to process the efficiency result from the heat pump calculator correctly.



#### 3.3.2 Low temperature heat pump for space heating only with a separate water heating heat pump


In this example all information is the same as the example in 3.3.1, but the "Type of water heating heat pump" is set to "Heat Pump" in the DEAP Entries tab and a separate water heating unit is specified. Again, the Heat Pump Calculator validates the basic entries made in specification of the heat pump. HP\_1 tab water heating entries are as follows in this example:

2 Heat Pump for Water Heating		
Manufacturer of the installed heat pump(s)	Acme heat pump manuf	
Model of the installed heat pump(s)	Acme heat pump HW model	
Type of heat pump	Air to Water	
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Fixed Outlet	
Describe the water heating heat pump arrangement	Separate Heat Pump providing Space Heating and Domestic Hot Water	
Water Heating Test Standard	I.S. EN 16147	
3 Output from Main Water Heater	2512.11	
1 Type of DHW	Separate Hot Water Storage	
1 Cold Water Inlet Temperature	10	
2 Required Flow Temperature from Heat Pump to Hot Water Storage	65	
3 Volume of DHW Storage	250	
Is there a water heater installed as back up for the heat pump	No	
	Flectricity	


Data is sourced for the water heating unit as would be done for a unit entered directly in the DEAP software. Example as follows:

Ecodesign based water heating tests to EN16147 (or EN13203-6 for GAHP)		
Source of data	Water heating energy efficiency, ηwh	
Water heating energy efficiency, ŋwh	90	%
Equivalent Coefficient of Performance	2.25	kW/kW
Reference Hot Water Temperature	54	°C
Required Source Temperature	7	°C
Capacity of Heat Pump	6	kW
Declared Load Profile	М	
Standby Heat Loss	1.2	kWh/day
Volume of DHW accounted for in test		litre

The results for space **and** water heating are now automatically updated in the DEAP Entries tab as follows and are populated in DEAP as per Table 3 and Table 4 above:



The space heating heat pump is entered in DEAP as an electric boiler as shown in Section 3.3.1. The water heating heat pump is as follows in DEAP:



#### 3.4 DX heat pump


Direct Exchange electric heat pumps follow the same guidance and use the same test standard (IS EN 14825) as electric Brine-to-water units. The main difference is that the source temperatures for space and water heating are  $4^{\circ}$ C rather than  $0^{\circ}$ C. This difference is automatically reflected in the Heat Pump Calculator. Key data entries for the space heating aspect of the DX heat pump are as follows for this example for a new dwelling:

Heat Pump for Space Heating		Valid space heat pump type selected.		
Manufacturer of the installed heat pump(s)	ACME heat pump manuf		Is this a Low Temperature Heat Pump?	Not low temperature heat pump
Model of the installed heat pump(s)	DirectEx640		Is this heat pump electric or gas (GAHP)?	Electricity
Type of heat pump	Direct exchange (DX)		What is the status of this heat pump regarding Ecodesign data?	Ecodesign applies and/or ecodesign o
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Variable Outlet		Source from Ecodesign Data	Diagnostics data in grey cells below of selections (these will be #NA if in selected in this section):
Space Heating Test Standard	Tonor Outer		Source Hom Leading, Build	Heat pump type: Direct exchange (
	I.S. EN 14825			

In this DX example, an excerpt from the space heating COP and capacity ecodesign data entered in the calculator is as follows. Note the "E4" source temperature rather than the "B0" value expected for a B/W unit.

High Temperature Application (55degC).	Source	E4	E4	E
Standard: I.S. EN 14825	Sink	W52	W42	W:
Source from Ecodesign data or I.S. EN14825 Table 10 for air source.	Heating Capacity (kW)	3.10	3.10	3.1
Table 14 for brine, water or DX source. [These table # references are from 2016 version of this standard]	Coefficient of Performance (kW/kW)	2.30	2.30	2.3

When "Direct Exchange" is selected for water heating, the data entered is again similar to that selected for Brine-to-water units, but with source temperature of  $4^{\circ}$ C automatically assigned by the Heat Pump Calculator.



The results for space **and** water heating from the DEAP Entries tab are populated in DEAP as per Table 3 and Table 4 above in the same way as the examples under sections 3.3.1 and 3.3.2

- Main space heating is entered as a "direct acting electric boiler"
- Fuel type is electricity

- The main space heater does not heat water. This enables the user to enter a separate efficiency for the main water heating provided by the heat pump.
- Water heater is fueled by electricity from the DEAP Entries tab, and efficiency adjustment factor = 1.0.
- Any renewable adjustment is accounted for in the dwelling Renewable Energy Ratio. In this example, the
  heat pump calculator showed a total renewable contribution adjustment <> 0. As this is a new dwelling,
  the RER adjustment <u>must</u> be carried out where an adjustment value is shown in the heat pump
  calculator. After the heat pump space and water heating systems above are entered in DEAP, then the
  Renewable Energy Ratio automatically derived in DEAP in this example is as follows:


	Source	Renewables Primary Energy	Total Primary Energy	RER
+ Delivered energy	PV/Wind	0.000	0.000	
+ Delivered energy	Other	0.000	0.000	
+ Delivered energy	Solar	0.000	0.000	
+ Delivered energy	Biomass	0.000	0.000	
+ Delivered energy	Biodiesel	0.000	0.000	
+ Delivered energy	Bioethanol	0.000	0.000	
+ Environmental energy	HP	5,823.629	5,823.629	
+ Saved energy	CHP	0.000	0.000	
+ District heating	District Heating	0.000	0.000	
+ Delivered energy	Grid	0.000	6,560.712	
+ Delivered energy	Thermal	0.000	0.000	
SUBTOTAL		5,823.629	12,384.342	0.470 🗸

These are imported by the Assessor back into the DEAP Entries tab of the heat pump calculator to derive the adjusted RER, which is in turn attached to the Part L compliance report and notified to the client. The RER in DEAP was 0.47, but the adjusted value relevant for Part L compliance is 0.46.

RESULTS: Part L compliance Renewable Energy Ratio (RER) Adjustment. Applies to New final and New provisional assessments only. BER Assessor must advise the client of any adjustment to RER, and attach details of adjusted RER to Part L compliance report. This section is completed AFTER the above heat pump calculation results are entered in DEAP software.					
Total renewable contribution adjustment	-306.43				
Total renewables primary energy from DEAP software	5823.63				
Total Primary Energy from DEAP software	12384.34				
Adjusted Renewable Energy Ratio to be attached to compliance report	0.46				

#### 3.5 GAHPs

Sourcing and entering data for gas fired heat pumps (GAHPs) is similar to electrically driven Air-to-water, Brine-to-water, and water-to-water heat pumps. The same mandatory ecodesign data requirements apply as electric heat pumps. The same ecodesign compliant test points and temperatures apply, but, as GAHP are not yet catered for in the DEAP software, the Heat Pump Calculator must be used. The standard for GAHPs for space heating is IS EN 12309-6 rather than IS EN 14825.



Backup heating and test data are entered in the same manner as for an electric heat pump, noting that the Heat Pump Calculator details the relevant tables in IS EN 12309-6 as per the following excerpt. The efficiency figures for GAHP are typically lower than electric heat pumps. However, this is offset somewhat in the final BER grade as electricity has a higher primary energy factor than natural gas / LPG.

Select the test Conditions according to the test data available from I.S. EN 12309-6	High Temperature Low Temperature Medium Temperature Very high Temperature	Yes Yes	Source from Ecodesign Data or accredited tests to I.S. EN 12309-6		ed tests to I.S. EN	GUIDANCE NOTE: High Temperature Application Data is a mandatory requirement under Ecodesign Directive for this heat pump so must be selected as well as any other temperature applications for which test data is available
	Maximum test temperature allowed for in tests to I.S. EN 12309-6 Test Conditions I.S. EN 12309-6	55 A (88%) -7°C	B (54%) 2°C	C (35%) 7°C	D (15%) 12°C	E* (100%) TOL
Low Temperature Application (35degC)	Source	A-7	A2	A7	A12	A-10
Standard: I.S. EN 12309-6  Source from Ecodesign data or I.S. EN12309-6 Table 5 for air source.  Table 17 for Brine or Water source.  [These table # references are from 2014 version of this standard]	Sink  Heating Capacity (kW)  Coefficient of Performance (kW/kW)	W35 3.50 1.60	W35 3.70 1.70	W35 4.70	W35 5.10 1.90	was 3.30 1.50


When the GAHP provides hot water, the guidance and sourcing of test data is similar to an electric heat pump, although the test standard is IS EN 13203-6 rather than IS EN 16147:

		wer		
		Valid water heat pump type selected.		
Manufacturer of the installed heat pump(s)	ACME heat pump manuf	Is this heat pump electric or gas (GAHP)?	Gas fired (GAHP)	
Model of the installed heat pump(s)	GAHP-AW-Y921U	What is the status of this heat pump regarding Ecodesign data?	Ecodesign applies and/or ecodesign data available	
Type of heat pump	Air to Water	Heat pump fuel primary energy factor (DHW)	1.10	
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Fixed Outlet	Source from Ecodesign Data	Diagnostics data in grey cells below showing summary of selections (these will be #NA if invalid options were selected in this section):	
Describe the water heating heat pump arrangement	Same Heat Pump providing Space Heating and Domestic Hot Water	Source from Designer/ Installer sign off sheet or site evidence without Ecodesign	Heat pump type: Air to Water	
Water Heating Test Standard	I.S. EN 13203-6		Electric or GAHP: Gas fired (GAHP)	


The DEAP Entries tab generates space and water heating efficiencies to be transferred into DEAP. See Table 3 and Table 4 for details:

- Main space heating is entered as a "regular non-condensing gas boiler"
- Fuel type is mains gas or LPG depending on the fuel used by the GAHP
- The main space heater does not heat water. This enables the user to enter a separate efficiency for the main water heating provided by the GAHP.
- Water heater is fueled by mains gas or LPG with efficiency from the DEAP Entries tab, and efficiency adjustment factor = 1.0.
- As the "Total renewable contribution adjustment" has a value of zero, no adjustment is required for renewables in this case

The space heating system in DEAP is as follows (and is a non-condensing regular gas boiler). The non-condensing boiler is selected as it enables DEAP to account for the efficiency from the heat pump calculator correctly and provides the user with the choice of suitable control options for a heat pump in DEAP.



Main water heating as is shown in the figure below for this GAHP.



#### 3.6 Exhaust Air-to-Air systems

Guidance for Double-duct heat pumps and heat recovery systems incorporating heat pump functionality Exhaust Air-to-Air heat pumps providing space heating are as per Section G4.3 of the DEAP Manual, however they differ from the Exhaust Air-to-Air heat pumps as the Exhaust Air to Air systems do not contain the Passive Heat Recovery element.

#### The DEAP Manual states:

- EN14511-2:2018 is used to test the performance of these units and this data can be used in DEAP. This includes data for the heat pump only from units tested to EN13141-7, as this standard requires the heat pump functionality to be tested to EN 14511-2.
- Source accredited EN14511-2 test data for the double duct air conditioner. As the required level of detail
  is not displayed in Ecodesign technical documentation or declarations of performance for these units,
  test data MUST be sourced on test certs from a suitably accredited body.

Follow the DEAP Manual G4.3 for guidance on sourcing and using space heating test data for Exhaust Air-to-air systems. Bear in mind that these systems are frequently installed with an accompanying hot water heat pump. This would be entered under the hot water section (similar to Section 3.3.2 above). The DEAP Entries tab is populated with the Exhaust Air space heating system and associated flowrate as per the following example:

Description: Heat pump # 1			
Type of space heating heat pump	Exhaust Air Heat Pump		
Type of water heating heat pump	Heat Pump		
% main space heat provided by each heat pump based on system design	100%		
% main water heat provided by each heat pump based on system design	100%		
Is heat pump source preconditioned?	No		
Is the Heat Pump part of a Group Heating Scheme	No		
If "Exhaust Air Heat Pump(s)" what is the total exhaust Air Flow Rate	44.00		

The appropriate standard for Exhaust Air to Air is selected for space heating in the HP\_1 tab following the quidance above:

Heat Pump for Space Heating		Valid space heat pump type selected.		
Manufacturer of the installed heat pump(s)	ACME heat pump manuf		Is this a Low Temperature Heat Pump?	Not low temperature heat pump
Model of the installed heat pump(s)	ACME heat pump model		Is this heat pump electric or gas (GAHP)?	Electricity
Type of heat pump	Exhaust Air to Air		What is the status of this heat pump regarding Ecodesign data?	Ecodesign doesn't apply and eco unavailable
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Fixed Outlet		Source from Ecodesign Data	Diagnostics data in grey cells below of selections (these will be #NA if in selected in this section):
Space Heating Test Standard	I.S. EN 13141			Heat pump type:Exhaust Air to Air

As this is a "to air" system, only "high temperature" application test points apply when entering space heating test data in the HP\_1 tab:

Select the test Conditions according to the test	High Temperature		Source from Ecodesian Data or accredited tests to LS	GUIDANCE NOTE: This is a 'to-air' heat pump. Select I
data available from I.S. EN 13141	Low Temperature	No		but High Temperature
1	Medium Temperature	No	<b>v</b>	
	Very high Temperature	No		

As it is an electric heat pump, then it is entered in DEAP as an electric boiler (in the same way as shown in the examples above). The exhaust air component will always result in an adjustment to the renewable energy contribution. Once the heat pump space and water heating systems are entered in DEAP, the renewable energy total and total primary energy are sourced from DEAP for use in the DEAP Entries tab, where the adjusted RER is calculated. This is then notified to the client as it is a new dwelling in this example, and attached to the Part L compliance report:

Total renewable contribution adjustment	-310.87
Total renewables primary energy from DEAP software	1567.00
Total Primary Energy from DEAP software	3496.00
Adjusted Renewable Energy Ratio to be attached to compliance report	<u>0.39</u>

# 3.7 Multiple Heat Pumps in Dwelling

The DEAP software cannot cater for multiple heat pumps within a dwelling.

Follow the guidance for entering the individual heat pumps is as per the DEAP Manual Appendix G.

This example shows the use of a Low Temperature Heat Pump providing the majority of the space heating and pre heats the Hot Water, also present is a Double Duct Heat Recovery Unit with Heat Pump functionality providing hot water and conditioning the air supplied through the ventilation system.

- Heat Pump 1 = Low Temperature Heat Pump for space heating and preheats hot water
- Heat Pump 2 = double duct heat recovery unit with HP functionality providing hot water.

Description:	Heat pump # 1	Heat pump # 2
Type of space heating heat pump	Heat Pump	Heat Pump
Type of water heating heat pump	Heat Pump	Heat Pump
% main space heat provided by each heat pump based on system design	80%	20%
% main water heat provided by each heat pump based on system design	30%	70%
Is heat pump source preconditioned?	No	No
Is the Heat Pump part of a Group Heating Scheme	No	No
If "Exhaust Air Heat Pump(s)" what is the total exhaust Air Flow Rate		

The user must then complete <u>each of tabs</u> HP\_1, and HP\_2, corresponding with the columns Heat pump#1, and Heat pump#2 respectively in the diagram above. On completion of data entry for HP\_1 and HP\_2, the heat pump calculator DEAP Entries tab shows a single space heating efficiency. Likewise, the water heating efficiency is derived by the heat pump calculator:

Heat pump#1: The Low Temperature Heat Pump Space Heating is entered as per 3.3.1 of this document.

Manufacturer of the installed heat pump(s)	Heat Pump Manu 1		Is this a Low Temperature Heat Pump?	Low temperature heat pump
- wandacturer of the histalied fleat pullp(s)	neat rump Manu 1		is this a cow remperature near rump:	tow temperature near pump
Model of the installed heat pump(s)	HP 123		Is this heat pump electric or gas (GAHP)?	Electricity
Type of heat pump	Air to Water		What is the status of this heat pump regarding Ecodesign data?	Ecodesign applies and/or ecodesign data available
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Variable Outlet			Diagnostics data in grey cells below showing summary of selections (these will be #NA if invalid options were selected in this section):
Space Heating Test Standard	I.S. EN 14825			Heat pump typesAir to Water
Operation Limit Temperature (TOL)	-10.00	°C	Source from Ecodesign Data	Electric or GAHP:Electricity
Heating water operating limit temperature (WTOL)	35.00	°C	Source from Ecodesign Data	Low temp:Low temperature heat pump

Select the test Conditions according to the test data available from I.S. EN 14825	High Temperature  Low Temperature  Medium Temperature  Very high Temperature	Yes No	Source from Ecodesign Data or accredited tests to I.S. EN 14825		d tests to I.S. EN	GUIDANCE NOTE: Low Temperature Application Data is a mandatory requirement under Ecodesign Directive for this heat pump so must be selected. If it is available, application data may also be selected at Medium Temperature
	Maximum test temperature allowed for in tests to I.S. EN 14825	35 A (88%)			D (15%)	E* {100%}
	Test Conditions I.S. EN 14825	-7°C	2°C 7°C 12°C		TOL	
Low Temperature Application (35degC)	Source	A-7	A2	A7	A12	A-10
Standard: I.S. EN 14825	Sink	W34	W30	W27	W24	W35
Source from Ecodesign data or	Heating Capacity (kW)	4.50	2.50	1.50	2.00	4.00
Table 12 for brine, water or DX source.  [These table #references are from 2016 version of this standard]	Coefficient of Performance (kW/kW)	3.00	4.00	5.00	6.00	2.00


• The Low Temperature Heat Pump is also partially heating the hot water, however as a Low Temperature Heat Pump it would not be on the market as a water heater and therefore would not be tested to EN 16147. Therefore, EN 14825/14511 test data may be used.

Manufacturer of the installed heat pump(s)	Heat Pump Manu 1	Is this heat pump electric or gas (GAHP)?	Electricity
Model of the installed heat pump(s)	HP 123	What is the status of this heat pump regarding Ecodesign data?	Ecodesign applies and/or ecodesign data available
Type of heat pump	Air to Water	Heat pump fuel primary energy factor (DHW)	2.08
Temperature Control (refered to as Capacity Control in Ecodesign Standard Template)	Variable Outlet	Source from Ecodesign Data	Diagnostics data in grey cells below showing summary of selections (these will be \$NA if invalid options were selected in this section):
Describe the water heating heat pump arrangement	Same Heat Pump providing Space Heating and Domestic Hot Water	Source from Designer/Installer sign off sheet or site evidence without Ecodesign	Heat pump type:Air to Water
Water Heating Test Standard	l.S. EN 14825/14511		Electric or GAHP:Electricity

- The COP and Capacity are based on 7°C outside temperature (or Point C in EN14825 test data) to match the source temperature used for DHW heat pump testing under EN16147.
- The reference hot water temperature is at the test condition, in this case 27°C (based on Point C of EN14825 for a variable control heat pump)
- For test data based on EN 14825/14511, the load profile, standby heat loss and volume of DHW accounted for in test are not applicable

Ecodesign based water heating tests to EN16147 (or EN13203-6 for GAHP)*				
Source of data	Coefficient of Performance, COP		Source from Ecodesign Data or accredited tests to EN 16147 (or EN13203-6 for GAHP)	
Coefficient of Performance, COP	5	kW/kW	Source from Ecodesign Data or accredited tests to EN 16147 (or EN13203-6 for GAHP)	
Equivalent Coefficient of Performance	5	kW/kW		
Reference Hot Water Temperature	27	°C	Source from Ecodesign Data or accredited tests to EN 16147, set at 40°C if unknown. (or EN13203-6 for GAHP)	
Required Source Temperature	7	°c	Based on Table 5 of EN 16147 (or EN13203-6 for GAHP)	
Capacity of Heat Pump	1.5	kW	Source from Ecodesign Data, manufacturers data or accredited tests to EN 16147 (or EN13203-6 for GAHP)	
Declared Load Profile	М		Source from Ecodesign Data, manufacturers data or accredited tests to EN 16147 (or EN13203-6 for GAHP)	Note: 'load profile', 'standby heat loss' and 'volume of DHW accounted for in test' are irrelevant for test data based on I.S. EN 14825/14511.
Standby Heat Loss		kWh/day	Source from Ecodesign Data or accredited tests to EN 16147 (or EN13203-6 for GAHP), set as 0 if unknown	
Volume of DHW accounted for in test		litre	Source from Ecodesign Data or accredited tests to EN 16147 (or EN13203-6 for GAHP)	

• Note; the reference hot water temperature limits the % share of DHW that can be provided by the heat pump. Heat Pump #2 will need to bring the hot water up to the adequate temperature.



Heat pump#2 the Double Duct Heat Recovery Unit space heating is as per DEAP Manual G4.3 and hot water is as per DEAP Manual G1.1 and is entered in the HP\_2 tab.

On completion of data entry for the two heat pumps, the heat pump calculator DEAP Entries tab shows a single space heating efficiency and is entered as a space heating in DEAP software. Likewise, the water heating efficiency and entered as a water heater in DEAP software as derived by the heat pump calculator:

Efficiency of space heating heat pump + backup	435.61%
Space heating fuel type	Electricity
Efficiency of water heating heat pump + backup	303.14%
Water heating fuel type	Electricity
Efficiency adjustment factor for space heating and water heating	1
Group heating % of heat from space heating	nła for individual system
Group heating % of heat from water heating	n/a for individual system

As it is an electric heat pump, then it is entered in DEAP as an electric boiler (in the same way as shown in the examples above).

Consideration should be given by the designers to the warnings highlighting where the heat pump will require back up heating. The designer should try to optimize the design for better efficiency (by limiting/ eliminating need for backup systems)

Additional errors and warnings:	Heat pump # 1 Warning: this heat pump requires backup to meet space heating load assigned to it.	Heat pump # 2 Warning: this heat pump requires backup to meet water heating load assigned to it.
---------------------------------	--	--

# 3.8 Group heating system examples

The DEAP software cannot yet cater for group heating heat pump calculations. Therefore, the Heat Pump Calculator must be used to generate the required efficiency data for DEAP.

#### 3.8.1 Group heating heat pump with group heating CHP / solar space heating / boilers


When entering a group heating heat pump, the yellow cells in the DEAP Entries tab are completed as per Table 2, such as in the following example for a block of apartments. This shows a system with a CHP system, secondary heating, and a heat pump. There is also a boiler solar space heating system contributing 47% of the boiler/heat pump / solar space heating heat. Therefore, the heat pump will do the remaining 53%, bringing to the required total of 100%. DEAP Appendix C states that:

"The proportions of heat from the CHP and from conventional boilers, and the heat and electrical efficiencies of the CHP for the calculation of CO<sub>2</sub> emissions, should be estimated, **either on the basis of operational records or in the case of a new scheme on the basis of its design specification.**"

#### And DEAP Section 10 states that

"DEAP allows for solar heating to contribute to the main space and main water heating of the dwelling. If this type of system is present, the proportion of group heating provided by the solar space and water heating system should be specified. This proportion is calculated using the method detailed on <a href="https://www.seai.ie/energy-in-business/ber-assessor-support/deap/">https://www.seai.ie/energy-in-business/ber-assessor-support/deap/</a>. "

The DEAP software section for the heat sources is as follows in this example, prior to completing the Heat Pump Calculator:



Data entered is entered in the DEAP Entries tab in this example as follows:


Description:	Value:		
Total heat loss (W/K) taken from DEAP	306.06		
Annual space heat requirement (total)	7106.06		
Floor Area of Dwelling	100.00		
Living area of dwelling	10.00		
Percentage of space heat from secondary system	10%		
Fraction of heat from CHP	0.12		
Output from main water heater	2512.11		
For Group Heating: Is charging based on heat consumed?	No		
Electricity Primary Energy Factor	2.08		
Volume of DHW Storage	250		
Description:	Heat pump # 1	Heat pump # 2	Heat pump # 3
Type of space heating heat pump	Heat Pump	None	None
Type of water heating heat pump	Heat Pump	None	None
% main space heat provided by each heat pump based on system design	53%	0%	0%
% main water heat provided by each heat pump based on system design	53%	0%	0%
Is heat pump source preconditioned?	No	No	No
Is the Heat Pump part of a Group Heating Scheme	Yes	No	No

The Heat Pump Calculator HP\_1 tab estimates the relevant total heat loss in watts for the apartments served by the heat pump for the total floor area served by the group heating system, as entered by the user:

Description:	Value:	Unit:	G
Total heat loss (WIK) taken from DEAP	306.06	WK	S fa
Heat Loss Watts	33445	Watts	R
Is this Heat Pump part of a Group Heating Scheme	Yes		
Proportion of main space heating provided by this heat pump	53%	%	
Floor Area of Dwelling	100.00	m2	s
If Heat Pump serves a Group Heat Scheme, the total Floor Area served by Heat Pump is:	1100.00	m2	s
Heat Pump for Space Heating		Valid space	heat pur
Manufacturer of the installed heat pump(s)	ACME heat pump manuf		Is
Model of the installed heat pump(s)	ACME heat pump modl grp		Is
Type of heat pump	Air to Water		\ E

The heat pump capacity is generally larger than that of a heat pump providing space and water heating to an individual dwelling:

Select the test Conditions according to the test data available from I.S. EN 14825	High Temperature Low Temperature Medium Temperature Very high Temperature	Yes Source from Ecodesign Data or accredited tests to I.S. EN 14825 Yes		GUIDANCE NOTE: High Temperature Application Data is a mandatory requirement under Ecodesign Directive for this heat pump so must be selected as well as any other temperature applications for which test data is available		
	Maximum test temperature allowed for in tests to I.S. EN 14825		B (54%)	C (35%)	D (15%)	E* (100%)
	Test Conditions I.S. EN 14825	-7-0	2°C	7°C	12°C	TOL
Low Temperature Application (35degC)	Source	A-7		A7	A12	
Standard: I.S. EN 14825	Source	A-7	A2	A/	A12	A-10
	Sink	W35	W35	W35	W35	W35
Source from Ecodesign data or I.S. EN14825 Table 8 for air source.	Heating Capacity (kW)	27.00	28.00	29.00	30.00	26.00
Table 12 for brine, water or DX source. [These table # references are from 2016 version of this standard]	Coefficient of Performance (kW/kW)	3.80	3.90	4.00	4.10	3.70
Medium Temperature Application (45degC)	Source			47	412	
Standard: I.S. EN 14825	Source	A-7 W45	A2 W45	A7 W45	A12 W45	
Source from Ecodesign data or	Heating Capacity (kW)	26.80		28.80	29.80	
I.S. EN14825 Table 9 for air source.	1					
Table 13 for brine, water or DX source. [These table # references are from 2016 version of this standard]	0.65 1.60 6 400400	0.50	0.50	0.70	0.000	
	Coefficient of Performance (kW/kW)	3.50	3.60	3.70	3.80	3.40
High Temperature Application (55degC).	Source	A-7	A-7	A-7	A-7	Δ-7




The DEAP Entries tab displays the data to complete the assessment:

Efficiency of space heating heat pump + backup	339.97%
Space heating fuel type	Electricity
Efficiency of water heating heat pump + backup	271.75%
Water heating fuel type	Electricity
Efficiency adjustment factor for space heating and water heating	1
Group heating % of heat from space heating	38.1%
Group heating % of heat from water heating	14.9%

When entering the group heating heat pump in DEAP, always enter the space heating efficiency and proportion as the first heat pump heating system, and the water heating heat pump efficiency and proportion as the second heat pump heating system in the DEAP group heating heat source section. First select "group scheme" and the level of heating controls:



Then enter the heat pump space heating efficiency and fuel type followed by the water heating efficiency and fuel type. Round their associated percentage of heat figures to the nearest integer for entry in DEAP. The remaining heat is met by solar space heating and a gas boiler:



#### 3.8.2 Multiple heat pumps in the group heating system

All examples thus far in this document have been for no more than a single space heating heat pump and single water heating heat pump (and most of the examples have been cases where the space and water heating are provided by the same unit). This meant that the HP\_1 tab is the only heat pump iteration used.

The heat pump calculator facilitates multiple heat pumps, and these may be in one of:

- a group heating configuration (i.e. all heat pumps heating multiple dwellings)
- an individual heating system configuration (i.e. all heat pumps only heating the single dwelling)
- a combination of group heating and individual heating configuration (e.g. heat pump(s) heating multiple dwellings in a group heating system in series with a heat pump within the dwelling).

The percentage of heat from each of the (up to three) heat pumps is based on data in the DEAP Entries tab:

Description:	Value:			Unit:
Total heat loss (W/K) taken from DEAP	306.06			W/K
Annual space heat requirement (total)	7106.06			kWh
Floor Area of Dwelling	100.00			m <sup>2</sup>
Living area of dwelling	10.00			m²
Percentage of space heat from secondary system	10%			%
Fraction of heat from CHP	0.12			0<=fraction <1
Output from main water heater	2512.11			kWh
For Group Heating: Is charging based on heat consumed?	No			
Electricity Primary Energy Factor	1.75			
Volume of DHW Storage	200			litres
Description:	Heat pump # 1	Heat pump # 2	Heat pump # 3	
Type of space heating heat pump	Heat Pump	None	None	
Type of water heating heat pump	Heat Pump	None	None	
% main space heat provided by each heat pump based on system design	27%	14%	19%	Total percentage=60%
% main water heat provided by each heat pump based on system design	15%	17%	21%	Total percentage=53%
Is heat pump source preconditioned?	No	No	No	
Is the Heat Pump part of a Group Heating Scheme	No	No	Yes	Group heating applies

Where there are three heat pumps providing space and water heating, a proportion of heat for each of space and water heating is required for each heat pump present as per the above example.

The user must then complete <u>each of HP\_1</u>, HP\_2, and HP\_3, corresponding with the columns Heat pump#1, Heat pump#2 and Heat pump#3 respectively in the diagram above. On completion of data entry for all three heat pumps, the heat pump calculator DEAP Entries tab shows a single space heating efficiency and proportion of space heat (entered under heating system 1 in DEAP software -> group heating heat sources). Likewise, the water heating efficiency and proportion (entered under DEAP software heating system 2) are derived by the heat pump calculator:

Efficiency of space heating heat pump + backup	466.55%
Space heating fuel type	Electricity
Efficiency of water heating heat pump + backup	197.75%
Water heating fuel type	Electricity
Efficiency adjustment factor for space heating and water heating	1
Group heating % of heat from space heating	43.1%
Group heating % of heat from water heating	14.9%

NB where there is one or more group heating heat pump in the system, then the heat pump calculator requires that the heating system is specified as a group heating system in DEAP. Where none of the heat pumps are in a group heating system (e.g. up to three individual heat pumps in a single system within the dwelling), use the HP 1, HP 2, HP 3 tabs and enter the results as individual space and water heating systems in DEAP using the "electric boiler" type system or "non condensing gas boiler" as per earlier examples in this document. .

#### **Sustainable Energy Authority of Ireland**

The Sustainable Energy Authority of Ireland, 3 Park Place, Hatch Street Upper, Dublin 2

- w: https://www.seai.ie/energy-in-business/ber-assessor-support/deap/
- e: registered@ber.seai.ie
- t: 1890 252 738 / 01 248 6986









